

## Canais e frequências em FM

Frequência		Frequência		Frequência	
Canal	MHz	Canal	MHz	Canal	MHz
201	88.1	234	94.7	267	101.3
202	88.3	235	94.9	268	101.5
203	88.5	236	95.1	269	101.7
204	88.7	237	95.3	270	101.9
205	88.9	238	95.5	271	102.1
206	89.1	239	95.7	272	102.3
207	89.3	240	95.9	273	102.5
208	89.5	241	96.1	274	102.7
209	89.7	242	96.3	275	102.9
210	89.9	243	96.5	276	103.1
211	90.1	244	96.7	277	103.3
212	90.3	245	96.9	278	103.5
213	90.5	246	97.1	279	103.7
214	90.7	247	97.3	280	103.9
215	90.9	248	97.5	281	104.1
216	91.1	249	97.7	282	104.3
217	91.3	250	97.9	283	104.5
218	91.5	251	98.1	284	104.7
219	91.7	252	98.3	285	104.9
220	91.9	253	98.5	286	105.1
221	92.1	254	98.7	287	105.3
222	92.3	255	98.9	288	105.5
223	92.5	256	99.1	289	105.7
224	92.7	257	99.3	290	105.9
225	92.9	258	99.5	291	106.1
226	93.1	259	99.7	292	106.3
227	93.3	260	99.9	293	106.5
228	93.5	261	100.1	294	106.7
229	93.7	262	100.3	295	106.9
230	93.9	263	100.5	296	107.1
231	94.1	264	100.7	297	107.3
232	94.3	265	100.9	298	107.5
233	94.5	266	101.1	299	107.7
				300	107.9